

Product
Continuous oven
Type
VDU 55/40/200-100°C

Application

Heating of dashboards for the polymerisation of adhesives

Branch

Automobile industry

Technical Data

Nominal temperature: 200°C,

Heat output: 40 kW

Input voltage

400 V 3(N) PE AC, 50/60 Hz

Inner dimensions:

Heating zone (3 control areas)

Width 1200 mm

Height 200 mm

Length 2400 mm

Outer dimensions

Width 1010 mm

Height 2040 mm

Total length 5620 mm

Feeding section 1700 mm

Removal section 1700 mm

System description

- Outer housing made of electrolytically galvanised steel sheet, painted (RAL 7032)
- Inner housing made of aluminised steel sheet
- 2 controlled heating groups
- Horizontal air flow injecting on both sides
- Crossbar belt conveyor
- Conveying equipment in cyclic operation

- Manual loading and unloading

Special features

- Pneumatic lift doors on the loading and removal side
- Controlling and monitoring with photoelectric barriers

