

Product Heating oven Type VTU 225/225/375-150°C

Application

Production of laminated safety glass panes for cars (Tempering under vacuum atmosphere)

Branch

Automotive and glass industry

Technical Data

Nominal temperature: 150°C,

Heat power: 110 kW

Nominal voltage:

3/N PE AC 400 V=/-10%, 50 Hz

Inner dimensions: Width 2250 mm Height 2250 mm Depth 3750 mm

Outer dimensions: Width 3050 mm (+240 mm for switch box) Height 3500 mm Depth 4250 mm

System description

- Outer housing made from electrogalvanised steel plate in **RAL 7032**
- Inner housing made from aluminised steel sheet
- recessed floor rails with wheel vehicle guide
- double-wing door with electric door lock
- working chamber lighting air flow horizontal from right to left
- 3 controls circuits, S!MCON 32 control system

Special features

- recessed floor rails for customer-provided trolley
- extra access ports for connection to external vacuum system
- internal lighting system





Global Partner for Environmental Test Chambers

Weiss Technik North America, Inc.

3881 N. Greenbrooke Dr. SE Grand Rapids, MI 49512 USA Tel: 1-800-368-4768 • (616) 554-5020

Fax: (616) 554-5021

www.weiss-na.com